



CDA-08 & CGA-08 Parts List

CA-002A	Air Motor	<i>Motor de Aire</i>
CA-002AG	Geared air motor	<i>Motor Electrico de engranaje</i>
CA-004	Aluminum Cover	<i>Cubierta de Aluminio</i>
CA-005A16	Cutter roller assy./air	<i>Rodillo cortador/aire</i>
CA-006	Blade retaining ring	<i>Partidario de navajas</i>
CA-007-PK	Cutter blades (12)	<i>Navajas paquete/12</i>
CA-007-100	Cutter Blades (100)	<i>Navajs paquete/100</i>
CA-008	Feed Roller assembly	<i>Rodillo proveedor (completo)</i>
CA-009	Feed Roller	<i>Rodillo proveedor</i>
CA-010	Anvil roller assembly	<i>Rodillo "anvil" (completo)</i>
CA-011	Anvil roller	<i>Rodillo "anvil" (plastico)</i>
CA-014	Cover Mounting Bushing	<i>Montaje de la cubierta casquillo</i>
CA-015	Cover Mounting Stud	<i>Montaje de la cubierta del perno</i>
CA-016	Shaft for Anvil/Feed Roller	<i>Eje del Junque / Rodillo</i>
CA-017	Set Screw Anvil/Feed Roller	<i>Set de tornillo del Junque/ Rodillo</i>

For warranty, instructions, diagrams
 Go to <http://esmfg.com/choppers.html>